

AEROSOL BELT DRESSING

FORMULA

<u>COMPOUND</u>	<u>%</u>
Polybutene	6.00
LPA Solvent	12.00
Cola [®] Cor 600	2.00
Water	62.00
A-31 Propellant	<u>18.00</u>
TOTAL	100.00

Dissolve polybutene in LPA. Add Cola[®]Cor 600. Fill as 2 liquid stages in can. Shake well before using. Chevron or BP-Amoco are polybutene sources.

Formula 194

Modified 07/26/2006

WARRANTY

Colonial Chemical guarantees that its products meet published specifications. No other warranties or guarantees are expressed or implied because the use of this material is beyond the control of Colonial Chemical.