



# Bubble Bath

Featuring Suga®Nate 160

<u>Phase</u>	<u>Compound</u>	<u>Weight %</u>
A	Water	41.2
A	Mineralizer (Water & Montmorillonite)	2.0
A	Glycerin	4.0
A	Cosmetic Xanthan Rapid-2 (Xanthan Gum)	0.4
B	<b>Suga®Nate 160</b>	50.0
B	Sweet Almond Oil	1.0
B	Fragrance	0.4
C	Eyuxyl K712 (Water & SodiumBenzoate & Potassium Sorbate)	1.0
		<u>100.00</u>

## PROCEDURE

At R/T, charge Phase A ingredients into main vessel and mix to uniformity. Premix Phase B ingredients in a side vessel to uniformity. Add Phase B to Phase A mixing carefully to avoid aeration. When uniform, add Phase C. Mix until batch is completely homogenous. Fill.

VOV004-62-2