



# Premium Aerosol Carpet Cleaner 2

<u>Compound</u>	<u>Wt%</u>
Water	69.00
Cola <sup>®</sup> Wet TDS-35	0.50
Cola <sup>®</sup> Mate SS-40	0.50
Colonial SM (15%)	23.50 (see below)
Cola <sup>®</sup> Cor AER	0.50
A-46 propellant	<u>6.00</u>
<b>TOTAL</b>	<b>100.0</b>

Formula to make Colonial SM resin 15% solution:

Deionized water	79.9
Colonial SM	15.0
Ammonium hydroxide 26%	<u>5.1</u>
<b>TOTAL</b>	<b>100.0</b>

Measure the water into a tank. Add the ammonium hydroxide and begin mixing. Slowly add Colonial SM and mix for at least 2 hours. Filter before use.

Colonial SM is a resin that prevents the re-deposition of soil on carpet fibers.

Dimethyl ether may be used as a propellant to reduce foaming but the amount will have to be increased to about 12% and the AER should be 1% minimum.

LAST UPDATED 05/21/2009

FORMULA NUMBER: 153

**WARRANTY**

Colonial Chemical guarantees that its products meet published specifications. No other warranties or guarantees are expressed or implied because the use of this material is beyond the control of Colonial Chemical.

**Colonial Chemical, Inc.**

[www.colonialchem.com](http://www.colonialchem.com)



ColonialChemical, Inc.