

PREMIUM AEROSOL CARPET CLEANER 1

<u>Component</u>	<u>Wt. %</u>
Water	68.38
COLA™ MATE SS-40	0.62
COLONIAL SLS	1.00
COLONIAL SM (15%)	23.50 (see below)
COLA™ COR AER	0.50
A-46 propellant	<u>6.00</u>
Total	100.00

Formula to make **COLONIAL SM** resin 15% solution:

Deionized water	79.9
COLONIAL SM	15.0
Ammonium hydroxide 26%	<u>5.1</u>
TOTAL	100.0

Measure the water into a tank. Add the ammonium hydroxide and begin mixing. Slowly add **COLONIAL SM** and mix for at least 2 hours. Filter before use.

COLONIAL SM is a resin that prevents the re-deposition of soil on carpet fibers.

Dimethyl ether may be used as a propellant to reduce foaming but the amount will have to be increased to about 12% and the AER should be 1% minimum.

Formula 148

Last Modified 07/5/2005

WARRANTY

Colonial Chemical guarantees that its products meet published specifications. No other warranties or guarantees are expressed or implied because the use of this material is beyond the control of Colonial Chemical.